

# CT102

**Centrale per un motore 230 Vac (120 Vac), per cancello scorrevole o portone basculante**  
*Control unit for a 230 Vac (120 Vac) motor, for a sliding gate or up-and-over door*  
*Logique de commande pour un moteur 230 Vca (120 Vca), pour portail coulissant ou*  
*porte basculante*

*Central para un motor 230 Vca (120 Vca), para puerta de corredera o portón basculante*  
*Steuergerät für einen Motor 230 Vac (120 Vac), für Schiebetor oder Schwingtor*  
*Unidade para um motor 230 Vac (120 Vac), para portão de correr ou portão basculante*  
*Centrala do silnika 230 Vac (120 Vac), napędzającego przesuwczą bramę ogrodzeniową*  
*lub uchylną bramę garażową*

# TABLE OF CONTENTS

<b>1</b>	<b>Safety warnings</b>	pag. 15
<b>2</b>	<b>Product Introduction</b>	pag. 16
2.1	Description of the control unit	pag. 16
2.2	Description of the connections	pag. 16
2.3	Models and technical characteristics	pag. 16
2.4	List of cables required	pag. 17
<b>3</b>	<b>Preliminary Checks</b>	pag. 17
<b>4</b>	<b>Installing the Product</b>	pag. 18
4.1	Electric connections	pag. 18
4.2	Limit switch fixing for 900CT102I	pag. 19
4.3	Electrobrake wiring diagram	pag. 19
4.4	Display during normal operation	pag. 20
4.5	Autolearning of the travel stroke	pag. 21
4.6	Customising the system - BASIC MENU	pag. 22
4.7	Connecting the radio receiver	pag. 23
<b>5</b>	<b>Testing and commissioning</b>	pag. 23
5.1	Testing	pag. 23
5.2	Commissioning	pag. 23
<b>6</b>	<b>Further details - ADVANCED MENU</b>	pag. 24
<b>7</b>	<b>Instructions and warnings for the final user</b>	pag. 25
<b>8</b>	<b>EC declaration of conformity</b>	pag. 87

# 1 - SAFETY WARNINGS

## ATTENTION !

**ORIGINAL INSTRUCTIONS - important safety instructions. Compliance with the safety instructions below is important for personal safety. Save these instructions.**

Read the instructions carefully before proceeding with installation.

**The design and manufacture of the devices making up the product and the information in this manual are compliant with current safety standards. However, incorrect installation or programming may cause serious injury to those working on or using the system. Compliance with the instructions provided here when installing the product is therefore extremely important.**

If in any doubt regarding installation, do not proceed and contact the Key Automation Technical Service for clarifications.

**Under European legislation, an automatic door or gate system must comply with the standards envisaged in the Directive 2006/42/EC (Machinery Directive) and in particular standards EN 12453; EN 12635 and EN 13241-1, which enable declaration of presumed conformity of the automation system.**

Therefore, final connection of the automation system to the electrical mains, system testing, commissioning and routine maintenance must be performed by skilled, qualified personnel, in observance of the instructions in the "Testing and commissioning the automation system" section.

The aforesaid personnel are also responsible for the tests required to verify the solutions adopted according to the risks present, and for ensuring observance of all legal provisions, standards and regulations, with particular reference to all requirements of the EN 12453 standard which establishes the test methods for testing door and gate automation systems.

## ATTENTION !

**Before starting installation, perform the following checks and assessments:**

ensure that every device used to set up the automation system is suited to the intended system overall. For this purpose, pay special attention to the data provided in the "Technical specifications" section. Do not proceed with installation if any one of these devices is not suitable for its intended purpose;

check that the devices purchased are sufficient to guarantee system safety and functionality;

perform a risk assessment, including a list of the essential safety requirements as envisaged in Annex I of the Machinery Directive, specifying the solutions adopted. The risk assessment is one of the documents included in the automation system's technical file. This must be compiled by a professional installer.

**Considering the risk situations that may arise during installation phases and use of the product, the automation system must be installed in compliance with the following safety precautions:**

never make modifications to any part of the automation system other than those specified in this manual. Operations of this type can only lead to malfunctions. The manufacturer declines all liability for damage caused by unauthorised modifications to products;

if the power cable is damaged, it must be replaced by the manufacturer or its after-sales service, or in all cases by a person with similar qualifications, to prevent all risks;

do not allow parts of the automation system to be immersed in water or other liquids. During installation ensure that no liquids are able to enter the various devices;

should this occur, disconnect the power supply immediately and contact a Key Automation Service Centre. Use of the automation system in these conditions may cause hazards;

never place automation system components near to sources of heat or expose them to naked lights. This may damage system components and cause malfunctions, fire or hazards;

all operations requiring opening of the protective housings of various automation system components must be performed with the control unit disconnected from the power supply. If the disconnect device is not in a visible location, affix a notice stating: "MAINTENANCE IN PROGRESS":

connect all devices to an electric power line equipped with an earthing system;

the product cannot be considered to provide effective protection against intrusion. If effective protection is required, the automation system must be combined with other devices;

the product may not be used until the automation system "commissioning" procedure has been performed as specified in the "Automation system testing and commissioning" section;

the system power supply line must include a circuit breaker device with a contact gap allowing complete disconnection in the conditions specified by class III overvoltage;

use unions with IP55 or higher protection when connecting hoses, pipes or cable glands;

the electrical system upstream of the automation system must comply with the relevant regulations and be constructed to good workmanship standards;

users are advised to install an emergency stop button close to the automation system (connected to the control PCB STOP input) to allow the door to be stopped immediately in case of danger;

this device is not intended for use by persons (including children) with impaired physical, sensory or mental capacities, or with lack of experience or skill, unless a person responsible for their safety provides surveillance or instruction in use of the device;

before starting the automation system, ensure that there is no-one in the immediate vicinity;

before proceeding with any cleaning or maintenance work on the automation system, disconnect it from the electrical mains;

special care must be taken to avoid crushing between the part operated by the automation system and any fixed parts around it;

children must be supervised to ensure that they do not play with the equipment.

## ATTENTION !

**The automation system component packaging material must be disposed of in full observance of current local waste disposal legislation. Packaging components (cardboard, plastic, etc.), duly separated, must be placed in the appropriate bins. Device components such as electronic boards, metal parts, batteries, etc. must be separated and differentiated. For the methods of disposal, the rules in force in the place of installation must be applied. DO NOT DISPOSE IN THE ENVIRONMENT!**




KEY AUTOMATION reserves the right to amend these instructions if necessary; they and/or any more recent versions are available at [www.keyautomation.com](http://www.keyautomation.com)

## 2 - INTRODUCING THE PRODUCT

### 2.1 - Description of the control unit

The CT102 control unit is the most modern, efficient system for the control of Key Automation motors for the electric opening and closure of sliding gates and up-and-over doors. All other, improper, use of the control unit is forbidden. The CT102 has

a display allowing easy programming and constant monitoring of the input status; the menu structure also allows easy setting of working times and operating modes.



### 2.2 - Description of the connections

- |  |   |
|--|---|
| <ul style="list-style-type: none"> <li>1- Motor power supply connections</li> <li>2- Capacitor connector</li> <li>3- 230 Vac (120 Vac) power supply connections to flashing and courtesy lights</li> <li>4- 24 Vdc power supply connection to controls and safety devices</li> <li>5- RED EDGE-PH2-PH1-STOP safety warning LEDs</li> <li>6- GREEN OPEN-CLOSE-PAR-SBS command indicator LEDs</li> <li>7- Radio PCB connector with RX4Y connection (4 channels)</li> <li>8- Antenna connector</li> <li>9- LCD display</li> <li>10- Limit switch connector</li> </ul> | <ul style="list-style-type: none"> <li>11- Limit switch indicator LED LS1</li> <li>12- Limit switch indicator LED LS2</li> <li>13- UP + button</li> <li>14- MENU button</li> <li>15- DOWN - button</li> <li>16- STEP BY STEP SBS button</li> <li>17- Safety device dip switch</li> <li>18- Transformer primary</li> <li>19- Transformer secondary</li> <li>20- F2- 500 mA rapid fuse protecting the accessories (with CT102I 800mAT slow-acting)</li> <li>21- F1- 6.3 A rapid fuse protecting the line</li> </ul> |
|--|---|

### 2.3 - Models and technical characteristics

CODE	DESCRIPTION
900CT102B	230 V control unit for sliding gates or up-and-over doors
900CT102V120	120 V control unit for sliding gates or up-and-over doors
900CT102I	230 V control unit for industrial sliding gates SC202MHD / SC252M

- Power supply with protection against short-circuits inside the control unit, on motors and on the connected accessories.
- Obstacle detection during travel at normal speed by means of current sensor.

- Automatic learning of working times.
- Safety device deactivation by means of dip switches: there is no need to bridge the terminals of safety devices which are not installed - the function is simply disabled by means of a dip switch.

TECHNICAL SPECIFICATIONS	900CT102B	900CT102V120	900CT102I
Power supply (L-N)	230 Vac (+10% - 15%) 50-60 Hz	120 Vac (+10% - 15%) 50-60 Hz	230 Vac (+10% - 15%) 50-60 Hz
Max motor load	700 W	700 W	700 W
Output for Vdc accessories power and device test power	24 Vdc 500 mA	24 Vdc 500 mA	24 Vdc 500 mA
Courtesy light output	230 Vac 100 W	120 Vac 100 W	230 Vac 100 W
Flashing light output	230 Vac 40 W	120 Vac 40 W	230 Vac 40 W
Pause time	Adjustable 0-900 sec.	Adjustable 0-900 sec.	Adjustable 0-900 sec.
Operating temperature	-20 °C + 55 °C	-20 °C + 55 °C	-20 °C + 55 °C
Accessory fuses (F2)	500mAF	500mAF	800mAT
Power supply line fuses (F1)	6,3AF	6,3AF	6,3AF

## 2.4 - List of cables required

The cables required for connection of the various devices in a standard system are listed in the cables list table.

The cables used must be suitable for the type of installation; for example, an H03VV-F type cable is recommended for indoor applications, while H07RN-F is suitable for outdoor applications.

### ELECTRIC CABLE TECHNICAL SPECIFICATIONS:

Connection	cable	maximum allowable limit
Control unit power supply line	1 x cable 3 x 1,5 mm <sup>2</sup>	20 m *
Flashing light, courtesy light Antenna	1 x cable 4 x 0,5 mm <sup>2</sup> ** 1 x cable type RG58	20 m 20 m (advised < 5 m)
Transmitter photocells	1 x cable 2 x 0,5 mm <sup>2</sup>	20 m
Receiver photocells	1 x cable 4 x 0,5 mm <sup>2</sup>	20 m
Sensitive edge	1 x cable 2 x 0,5 mm <sup>2</sup>	20 m
Key-switch	1 x cable 4 x 0,5 mm <sup>2</sup>	20 m

\* If the power cable is longer than 30 m, a cable with a larger cross-section is required (3x2.5 mm<sup>2</sup>) and safety earthing is necessary in the vicinity of the automation.

\*\* Two cables of 2 x 0.5 mm<sup>2</sup> can be used as an alternative

## 3 - PRELIMINARY CHECKS

Before installing the product, perform the following checks and inspections:

check that the gate or door is suitable for automation;

the weight and size of the gate or door must be within the operating limits specified for the automation system in which the product is installed;

check that the gate or door has firm, effective mechanical safety stops;

make sure that the product fixing zone is not subject to flooding;

high acidity or salinity or nearby heat sources might cause the product to malfunction;

in case of extreme weather conditions (e.g. snow, ice, wide temperature variations or high temperatures), friction may increase, causing a corresponding rise in the force needed to operate the system;

the starting torque may therefore exceed that required in normal conditions;

check that when operated by hand the gate or door moves smoothly without any areas of greater friction or derailment risk;

check that the gate or door is well balanced and will therefore remain stationary when released in any position;

check that the electricity supply line to which the product is to be connected is suitably earthed and protected by an overload and differential safety breaker device;

the system power supply line must include a circuit breaker device with a contact gap allowing complete disconnection in the conditions specified by class III overvoltage;

ensure that all the material used for installation complies with the relevant regulatory standards.

# 4 - PRODUCT INSTALLATION

## 4.1 - Electrical connections

WARNING - Before making the connections, ensure that the control unit is not powered up.

### MOTOR CONNECTOR

Power supply connection terminal board

L1	Motor live
COM	Motor common
L2	Motor live
COND	Motor capacitor

### MOTOR LIMIT SWITCH CONNECTION

LS1	Limit switch 1 input
COM	Limit switch common
LS2	Limit switch 2 input



### POWER SUPPLY CONNECTOR

L	Power supply live 230 Vac (120 Vac) 50-60 Hz
N	Power supply neutral 230 Vac (120 Vac) 50-60 Hz
COM Vac	Common of the "CR" and "FLASH" outputs
CR	Courtesy light, 230 Vac (120 Vac) 100 W, output controllable also via radio ON-OFF command (radio channel 4 selecting $F.C.Y. = 2, E.C.Y. = 0$ )
FLASH	Flashing light, 230 Vac (120 Vac) 40 W


### DIP SWITCH

Set on "ON" to disable inputs EDGE, PH2, PH1, STOP. Eliminates the need to bridge the terminal board inputs.


**WARNING - with the dip switch ON, the safety devices are disabled**



4.2 - Limit switch fixing for 900CT1021



4.3 - Electrobrake wiring diagram



## SAFETY AND CONTROL DEVICE CONNECTOR

+24 Vdc	Accessories power supply positive 24 Vdc, 250 mA
NEG	Accessories power supply negative
PH-POW	Photocells PH1 and PH2 power supply positive; phototest can be selected with parameter $t^{Ph}$ 24 Vdc, 250 mA
EDGE	Safety sensor edge, ON/OFF NC contact or resistive 8K2 between EDGE and EDGE (warning, with dip switch 1 ON the safety EDGE input is off)
PH2	Photocells (opening), NC contact between PH2 and COM (warning, with dip switch 2 ON the PHOTOCELL 2 safety device input is off) The photocell is tripped at any time during opening of the automation system, halting operation immediately; the automation system will continue opening when the contact is restored.
PH1	Photocells (closing), NC contact between PH1 and COM (warning, with dip switch 3 ON the PHOTOCELL 1 safety device input is off) The photocell is tripped at any time during closing of the automation system, halting operation immediately and reversing the travel direction
STOP	STOP safety device, NC contact between STOP and COM (warning, with dip switch 4 ON the STOP safety device input is off) This input is classified as a safety device; the contact can be deactivated at any time, cutting out the automation system and disabling all functions, including Automatic Closure
OPEN	OPEN command NO contact between OPEN and COM Contact for the HOLD-TO-RUN function. The gate OPENS as long as the contact is held down
CLOSE	CLOSE command NO contact between CLOSE and COM Contact for the HOLD-TO-RUN function. The gate CLOSES as long as the contact is held down
PAR	PARTIAL command NO contact between PAR and COM Used to open the gate partially, depending on the software setting
SBS	STEPPING command NO contact between SBS and COM Open/Stop/Close/Stop command, or as set in the software
COM	Common for the PH1, PH2, STOP, OPEN, CLOSE, PAR and SBS inputs
SIGNAL	Antenna - signal -
SHIELD	Antenna - shield -

### 4.4 - Display during normal operation

In "NORMAL OPERATING MODE", i.e. when the system is powered up normally, the 3-figure LCD display shows the following status messages:

MESSAGES	MEANING
--	Gate closed or switch-on after shutdown
OP	Gate opening
CL	Gate closing
SO	Gate stopped during opening
SC	Gate stopped during closure
HA	Gate stopped by external event
oP	Gate stopped without automatic reclosure
PE	Gate in partial opening position without automatic reclosure
-tL	Gate open with timed reclosure Flashing dash counting in progress Dash replaced by figures 0..9 countdown (last 10s)
-tP	Gate in partial opening position with timed reclosure Flashing dash counting in progress Dash replaced by figures 0..9 countdown (last 10s)
L--	Learning started on limit switch (move the gate off the limit switch to continue the learning procedure)
LDP	Learning opening
LCL	Learning closure

In addition, the dots between the figures illustrate the status of the limit switches, as described in greater detail below:

MESSAGES	MEANING
-.-	Limit switch CLOSING (one dot between the two lines)
tL.	Limit switch OPENING (a point to the right)
SO	No limit switch active (no dots present)



## Malfunctions

This section lists a number of malfunctions which may occur.

<b>SURGE OVERLOAD ALARM</b>	The motor's current drawdown has increased very quickly
<i>EFD</i>	1. The gate has struck an obstacle. 2. Friction on runners or rack.
<b>SAFETY EDGE ALARM</b>	The control unit has received a signal from the safety edge
<i>EEd</i>	1. The safety edge has been pressed. 2. The safety edge is not connected correctly.
<b>LIMIT SWITCH ALARM</b>	The limit switches are not working properly
<i>ELS</i>	1. The limit switches are damaged. 2. The limit switches are not connected. 3. Check the travel time which has passed without tripping of the limit switches.
<b>PHOTOCELL ALARM</b>	Phototest fail outcome.
<i>EPH</i>	1. Check the photocell connections. 2. Check that the photocells are operating correctly.
<b>ELECTRONIC OVERLOAD CUTOUT TRIPPED</b>	Motor not absorbing power
<i>Eth</i>	1. Check the motor's power drawdown. 2. Check that the gate travels smoothly and that there are no obstacles.

After eliminating the cause of the alarm, to delete all errors simply press the "DOWN -" key or press the SBS (STEP BY STEP) command

The display returns to the normal screen.

## 4.5 - Autolearning of the travel stroke

The first time the control unit is powered up, an autolearning procedure must be carried out to acquire fundamental parameters such as the travel stroke length and deceleration points.

Press the + or - keys to view not only the status of the control unit, as explained in the first table in point 4.2, but also the count of the ope-


ning-closing operations performed. In the operation count display, thousands, displayed without dots, alternate with units, displayed with dots between them (e.g.: 50.000 = 50/0.0.0).

### AUTOLEARNING OF THE TRAVEL STROKE AND MAIN PARAMETERS, WITH PRESET DECELERATIONS

The decelerations will be those set in the menu, with the same percentage during both opening and closing.

To program the decelerations in manual mode, move straight on to the next table.


1. Release the gate or door, move it onto the central position and lock it in place again. For customised programming of decelerations, move on to the next section.
2. Hold down the + and MENU buttons SIMULTANEOUSLY for more than 5 seconds, until the screen shows *LQP* and get ready to press the DOWN key (see illustration) if necessary.
3. If the first operation is NOT opening of the gate, press the DOWN key to stop the autolearning. Then press SBS to restart the acquisition: the gate starts moving again, in the right direction. The motor opens the gate at low speed to the opening limit switch (if the torque is not sufficient to move the gate, delete the decelerations from the menu [*L5l* =0]). When the open limit switch is reached, the gate sets off again in the closing direction at full speed, displaying *LLL*.
4. Wait for two complete operating cycles (2 opening and 2 closing strokes) to be completed and for the gate to finish travel in the closed position (displaying --).
5. Perform a number of opening, closing and sudden stop commands to ensure that the system is solid with no assembly defects.



All the main parameters are set with the default settings by the control unit. To customise the installation, proceed as described in point 4.4 below.

## AUTOLEARNING OF THE TRAVEL STROKE AND MAIN PARAMETERS, WITH CUSTOMISED DECELERATIONS

1. Release the gate or door, move it onto the central position and lock it in place again.
2. Access the basic menu to set parameter  $L5i = P$  as shown in the table in point 4.4.
3. Hold down the + and MENU buttons SIMULTANEOUSLY for more than 5 seconds, until the screen shows  $LDP$  and get ready to press the DOWN key (see illustration) if necessary.
4. If the first operation is NOT opening of the gate, press the DOWN key to stop the autolearning. Then press SBS to restart the acquisition: the gate starts moving again, in the right direction.
5. The motor opens the gate at low speed to the opening limit switch (if the torque is not sufficient to move the gate, delete the decelerations from the menu [ $L5i = 0$ ]). When the open limit switch is reached, the gate sets off again in the closing direction at full speed, displaying  $LCL$ .
6. When the gate reaches the point where you wish closing deceleration to start, give an SBS command. The gate will continue to travel at low speed.
7. When the limit switch is reached, the gate will start to open at full speed.
8. When the gate reaches the point where you wish opening deceleration to start, give an SBS command. The gate will continue to travel at low speed.
9. When the open limit switch is reached, the gate will close automatically, performing the programmed travel stroke.



All the main parameters are set with the default settings by the control unit. To customise the installation, proceed as described in point 4.4 below.

### 4.6 - Customising the system - BASIC MENU

If necessary, users may select a BASIC MENU which allows modification of the control unit's basic parameters. To select the BASIC MENU proceed as described below.

**WARNING:** to be certain of accessing the NORMAL OPERATION display state, the starting point for accessing the BASIC MENU, press the MENU key twice

Exempling of modifying a BASIC MENU parameter



Press the MENU key for 1 second to access the basic menu.



After accessing the BASIC MENU, press the + and - keys to scroll through the functions.



To access the value modification function, press the MENU key for 1 second, until the value starts to flash quickly.



Press the + and - keys to modify the value.



Press the MENU key for 1 second to display the parameter in order to save the modified value, or MENU quickly to quit the function without saving.



Press the + and - keys to scroll through the functions to modify other parameters.



Press the MENU key quickly to quit the menu.

PARAMETERS	DESCRIPTION	DEFAULT CONFIGURATION	MIN	MAX	UNIT
1	$t_{CL}$	Automatic reclosure time (0 = off)	20	0	900 s
2	$t_{tr}$	Reclosing time after transit (0 = off)	0	0	30 s
3	$t_{r9}$	Motor force (peak torque)	100	10	100 % (step of 10)
4	$SS_L$	Deceleration mode 0 = 1/3 deceleration 1 = 2/3 deceleration	0	0	1
5	$SbS$	SBS configuration: 0 = Normal (AP-ST-CH-ST-AP-ST...) 1 = Alternate STOP (AP-ST-CH-AP-ST-CH...) 2 = Alternate (AP-CH-AP-CH...) 3 = Apartment block – timer 4 = Apartment block with immediate reclosure	0	0	4
6	$b_{Lk}$	Post blackout procedure 0 = no action, remains stationary 1 = Closure	0	0	1
7	$SS_t$	Soft start 0 = off 1 = on	0	0	1
8	$L_{S1}$	Deceleration distance P = customised by learning 0...100% = percentage of travel stroke	15 *	0	100 % (step of 1)

\* for 900CT102I default value = 0

#### 4.7 Connecting the radio receiver

Connect the radio receiver, removing the plastic cover and taking care to position it as shown in the diagram in point 2.1. For programming, follow the receiver instructions, remembering that

the 4 outputs which can be activated are:  
OUTPUT 1 = STEP BY STEP, OUTPUT 2 = PARTIAL, OUTPUT 3 = OPEN, OUTPUT 4 = LIGHT ON-OFF.

## 5 - TESTING AND COMMISSIONING THE AUTOMATION SYSTEM

The system must be tested by a qualified technician, who must perform the tests required by the relevant standards in relation to the risks present, to check that the installation complies with the

relevant regulatory requirements, especially the EN12453 standard which specifies the test methods for gate and door automation systems.

### 5.1 Testing

All system components must be tested following the procedures described in their respective operator's manuals;

ensure that the recommendations in Chapter 1 - Safety Warnings - have been complied with;

check that the gate or door is able to move freely once the automation system has been released and is well balanced, meaning that it will remain stationary when released in any position;

check that all connected devices (photocells, sensitive edges, emergency buttons, etc.) are operating correctly by performing gate or door opening, closing and stop tests using the connected control devices (transmitters, buttons or switches);

perform the impact measurements as required by the EN12453 standard, adjusting the control unit's speed, motor force and deceleration functions if the measurements do not give the required results, until the correct setting is obtained.

### 5.2 Commissioning

Once all (and not just some) of the system devices have passed the testing procedure, the system can be commissioned;

the system's technical dossier must be produced and kept for 10 years. It must contain the electrical wiring diagram, a drawing or photograph of the system, the analysis of the risks and the solutions adopted to deal with them, the manufacturer's declaration of conformity for all connected devices, the operator's manual for every device and the system maintenance plan;

fix a dataplate with the details of the automation, the name of the person who commissioned it, the serial number and year of construction and the CE marking on the gate or door;

also fit a sign specifying the procedure for releasing the system by hand;

draw up the declaration of conformity, the instructions and precautions for use for the end user and the system maintenance plan and consign them to the end user;

ensure that the user has fully understood how to operate the system in automatic, manual and emergency modes;

the end user must also be informed in writing about any risks and hazards still present;

#### ATTENTION !

**after detecting an obstacle, the gate or door stops during its opening travel and automatic closure is disabled; to restart operation, the user must press the control button or use the transmitter.**

## 6 - FURTHER DETAILS - ADVANCED MENU

The ADVANCED MENU allows the system to be further customised by modifying parameters not accessible from the basic menu

To access the ADVANCED menu, press the MENU key and hold it

down for 5 seconds

To modify ADVANCED MENU parameters, proceed as described for the BASIC MENU

PARAMETERS	DESCRIPTION	DEFAULT CONFIGURATION	MIN	MAX	UNIT
1	<i>EL.F.</i> Electric brake 0 = off 1 = on	0	0	100	x 0.01s (step of 5)
2	<i>SP.h.</i> Use of PHOTO1 when starting from closed 0 = PHOTO1 is checked 1 = The gate starts even with PHOTO1 excited	1	0	1	
3	<i>Ph.2.</i> Use of PHOTO2 0 = Enabled during both opening and closing AP/CH 1 = Only enabled during opening AP	0	0	1	
4	<i>tP.h.</i> Photo-device test 0 = off 1 = PHOTO1 on 2 = PHOTO2 on 3 = PHOTO1 and PHOTO2 on	0	0	3	
5	<i>Ed.ñ.</i> Sensitive edge type 0 = contact (NC) 1 = resistive (8k2)	1	0	1	
6	<i>IE.d.</i> Sensitive edge tripping mode 0 = only tripped during closure with direction reversal 1 = stops the automation (during both opening and closure) and retreats from the obstacle	0	0	1	
7	<i>tE.d.</i> Edge test 0 = off 1 = on	0	0	1	
8	<i>LP.o.</i> Partial opening	30	0	100	% (step of 1)
9	<i>tP.C.</i> Time for automatic closure from partial opening (0=off)	20	0	900	s
10	<i>FP.r.</i> Flashing light output setup 0 = Steady 1 = Flashing	1	0	1	
11	<i>tP.r.</i> Pre-flashing time (0 = off)	0	0	10	s
12	<i>FC.y.</i> Courtesy light setup 0 = On at end of operation for time TCY 1 = On if gate not closed + duration of TCY 2 = On if courtesy light timer (TCY) time not out 3 = Gate open light on/off 4 = Gate open light proportional flashing	0	0	4	
13	<i>tC.y.</i> Courtesy light on time	0	0	900	<sup>s</sup> (step of 10s)
14	<i>dE.A.</i> Hold-to-run 0 = off 1 = on	0	0	1	
15	<i>SE.r.</i> Service interval cycle threshold. Once the set threshold is reached, the light flashes at high speed in all subsequent cycles (only if FPR is on). (0 = off)	0	0	100	x 1000 cycles
16	<i>SE.F.</i> Enabling of continuous flashing indicating service required (only active with gate closed). 0 = off 1 = on	0	0	1	
17	<i>dE.F.</i> Restoring the default values				

To set the default values: 1) access the advanced programming function; 2) select the "dEF" parameter; 3) activate the modification mode ("0" on display); 4) accept the modification (press "MENU"

and hold it down). A countdown should now appear: d80,d79...,d01 down to "don". Release the key when finished.

## 7 - INSTRUCTIONS AND WARNINGS FOR THE END USER

Key Automation S.r.l. produces systems for the automation of gates, garage doors, automatic doors, roller blinds and car-park and road barriers. However, Key Automation is not the manufacturer of your complete automation system, which is the outcome of the analysis, assessment, choice of materials and installation work of your chosen installer. Every automation system is unique, and only your installer has the experience and skill required to produce a safe, reliable, durable system tailored to your needs, and above all that complies with the relevant regulatory standards. Although your automation system complies with the regulation safety level, this does not rule out the presence of "residual risk", meaning the possibility that hazards may occur, usually due to reckless or even incorrect use. We would therefore like to give you some advice for the correct use of the system:

- before using the automation system for the first time, have the installer explain the potential causes of residual risks to you;
- keep the manual for future reference, and pass it on to any new owner of the automation system;
- reckless use and misuse of the automation system may make it dangerous: do not operate the automation system with people, animal or objects within its range of action;
- a properly designed automation system has a high level of safety, since its sensor systems prevent it from moving with people or obstacles present so that its operation is always predictable and safe. However, as a precaution children should not be allowed to play close to the automation system, and to prevent involuntary activation, remote controls must not be left within their reach;
- as soon as any system malfunction is noticed, disconnect the electricity supply and perform the manual release procedure. Never attempt repairs on your own; call in your installation engineer. In the meantime the door or gate can be operated without automation once the geared motor has been released using the release key supplied with the system. In the event of safety devices out of service arrange for repairs to the automation immediately;
- in the event of malfunctions or power failures: while waiting for the engineer to come (or for the power to be restored if your system is not equipped with buffer batteries), the door or gate can be used just like any non-automated installation. To do this, the manual release procedure must be carried out;
- manual release and operation: first bear in mind that the release procedure can only be carried out with the door or gate stationary.

- Maintenance: Like any machine, your automation system needs regular periodic maintenance to ensure its long life and total safety. Arrange a periodic maintenance schedule with your installation engineer. Key Automation recommends that maintenance checks should be carried out every six months for normal domestic use, but this interval may vary depending on the level of use. Any inspection, maintenance or repair work must only be carried out by qualified staff.

- Never modify the automation system or its programming and setup parameters: this is the responsibility of your installation engineer.

- Testing, routine maintenance and any repairs must be recorded by the person who performs them and the documents must be conserved by the system's owner.


The only procedures you are capable of, and which you are recommended to perform, are cleaning of the photocell glass and removal of any leaves or stones that may obstruct the automation system. To prevent anyone from activating the gate or door, release the automation system before starting. Clean only with a cloth dipped in a little water.

At the end of its useful life, the automation system must be dismantled by qualified personnel, and the materials must be recycled or disposed of in compliance with the legislation locally in force.

If after some time your remote control seems to have become less effective, or stops operating completely, the battery may be flat (depending on the level of use, this may take from several months up to more than a year). You will realise this because the transmission confirmation light does not come on, or only lights up for a very short time.

Batteries contain pollutants: do not dispose of them with normal waste but follow the methods specified by the local regulations.

Thank you for choosing Key Automation S.r.l.; please visit our Internet site [www.keyautomation.com](http://www.keyautomation.com) for further information.



### DICHIARAZIONE DI INCORPORAZIONE DI QUASI-MACCHINA

#### DECLARATION OF INCORPORATION OF PARTLY COMPLETED MACHINERY

Il sottoscritto Nicola Michelin, Amministratore Delegato dell'azienda  
*The undersigned Nicola Michelin, General Manager of the company*

Key Automation S.r.l., Via Meucci, 23 - 30027 San Donà di Piave (VE) – ITALIA

dichiara che il prodotto tipo:  
*declares that the product type:*

#### GO 230

Centrali di comando 230Vac o 120Vac per l'automazione di cancelli a 1 o 2 motori  
*230Vac or 120Vac Control units for gates up to 2 motors*

Modello:  
*Model:*

850CT102B, 850CT102I, 850CT102V120  
850CT202, 850CT202V120, 800CT202, 800CT202L

E' conforme a quanto previsto dalle seguenti direttive comunitarie:  
*Is in conformity with the following community (EC) regulations:*

Direttiva macchine / *Machinery Directive 2006/42/EC*  
Direttiva compatibilità elettromagnetica / *EMC Directive 2014/30/EU*  
Direttiva bassa tensione / *Low voltage Directive 2014/35/EU*  
Direttiva RoHS / *RoHS Directive 2011/65/EU*

Secondo quanto previsto dalle seguenti norme armonizzate:  
*In accordance with the following harmonized standards regulations:*

EN 55014-1:2006 + A1:2009 + A2:2011  
EN 55014-2:1997 + A1:2001 + A2:2008  
EN 62233:2008  
EN 60335-1:2012 + A1 + A11, EN 60335-2-103:2015  
EN 61000-3-2:2014, EN 61000-3-3:2013  
EN 61000-6-2:2005, EN 61000-6-3:2007  
EN 60950-1:2006: + A11:2009 + A1:2010 + A12:2011 + A2:2013

Dichiara che la documentazione tecnica pertinente al prodotto è stata redatta conformemente a quanto previsto dalla direttiva 2006/42/CE Allegato VII parte B e verrà fornita a fronte di una richiesta adeguatamente motivata dalle autorità nazionali.  
*Declares that the technical documentation is compiled in accordance with the directive 2006/42/EC Annex VII part B and will be transmitted in response to a reasoned request by the national authorities.*

Dichiara altresì che non è consentita la messa in servizio del prodotto finché la macchina, in cui il prodotto è incorporato, non sia stata dichiarata conforme alla direttiva 2006/42/CE.  
*He also declares that is not allowed to use the above mentioned product until the machine, in which this product is incorporated, has been identified and declared in conformity with the regulation 2006/42/EC.*

San Donà di Piave (VE), 12/07/17

Amministratore Delegato  
General Manager  
Nicola Michelin



Key Automation S.r.l.  
Via Meucci, 23  
30027 San Donà di Piave (VE)  
P.IVA 03627650264 C.F. 03627650264  
[info@keyautomation.it](mailto:info@keyautomation.it)

Capitale sociale 154.000,00 i.v.  
Reg. Imprese di Venezia 03627650264  
REA VE 326953  
[www.keyautomation.it](http://www.keyautomation.it)



Organizzazione con sistema di gestione certificato  
ISO 9001:2008

**Key Automation S.r.l.**

Via Meucci 23 - 30027 San Donà di Piave (VE)

T. +39 0421 307456 - F. +39 0421 65698

info@keyautomation.it - www.keyautomation.com

Instruction version  
580ISCT102B REV.12